



Operators Manual & Parts List

**CYCLONE
HEAVY DUTY MOWER**

MJ30-560HD

An aerial photograph showing a green tractor with a large mower attachment working in a field of tall grass. The tractor is moving from right to left, leaving a distinct track in the grass. The field is vast and green, with some brown patches of earth visible in the distance.

CYCLONE

Head Office

Major Equipment Intl. Ltd.
Ballyhaunis,
Co. Mayo,
Ireland.

Tel.: +353 (0) 9496 30572
Fax: +353 (0) 9496 30788
Email: info@major-equipment.com

UK Office

Major Equipment Ltd.
Major Industrial Estate,
Middleton Rd.,
Heysham,
Lancs.
LA3 3JJ

Tel.: +44 (0) 1524 850 501
Fax: +44 (0) 1524 850 502
Email: ukinfo@major-equipment.com

NETHERLANDS & GERMANY OFFICE

Major Equipment Intl. Ltd.
Postbus 29,
NL-7700 AA ,
Dedemsvaart,
Nederland.

Tel: +31 (0) 6389 19585
Email: euinfo@major-equipment.com

Web: www.major-equipment.com



Find us on FACEBOOK
MAJOR MACHINERY



View our channel
MAJOREQUIPMENT

Disclaimer

While every effort has been made in the production of this manual to ensure that the information contained herein is full and correct, Major assumes no responsibility for errors or omissions.

Major reserves the right to modify the machinery and the technical data contained within the manual without prior notice.

Further to this, Major assumes no liability for any damages which may result from the use of the information contained within this manual.

Contents

Introduction

Thank you	1
Safety Aspects	1
Intended use	1
Register Your Product and Warranty Online	1
Tractor Requirements	2

Safety

Hazards associated with operating Grass Cutting Machinery	2
Operating Safely	3
Workstation	4
Regulations for use of the transmission	4
PTO Shaft Safety	4
Driving Safely on Public Roads	5
Inspections before Use	6
Starting Regulations	6

Product Identification

Machine Serial Numbers	7
Product Specifications	7
EEC certificate of conformity for machines	8
Machine Safety Labels	9
Key to Main Parts	10
Blade Rotation	11
Blade system	12
Drive-line gearboxes	12

Operating the Machine

Attaching machine to the Tractor	13
Transport Position	14
Operating the Machine/Mowing	15
Additional adjustments	16
Roller and skid setup	16
Castor wheel	17

Maintenance

Machine storage	18
PTO Shaft Maintenance	18
Transmission Bolts	19
Roller	19
Replacement of wear parts	19
Clearing out a blockage	19
Wing shafts alignment	19
Troubleshooting	20
Lubrication schedule	22
Spinning Undersole Disk <i>(if applicable)</i>	22

Spare Parts - CYCLONE

MJ30-560HD Overview	23
MJ30-560HD Body Assembly	24
MJ30-560HD Wing Assembly	27
Front Guards assembly MJ30-560HD	30
MJ30-560HD Wing PTO assembly (WS601650-S)	31
MJ30-560HD PTO shaft	31
PTO shaft (606606) 1-3/4”(20)	32
Hydraulics (MJ30-560HD)	33
MJ30-560HD Blade assemblies	34
Spinning Undersole Disk Assembly (USD-GA1)	35
LF140T/1 (140.886) (140.881) (1)	36
T292B/2 (292.005) (1.47)	37

Introduction

Thank you

We appreciate having you as a customer and wish you many years of safe and satisfied use of your machine.

Safety Aspects

This manual is an important part of your machine and should remain with the machine when you buy it. Reading your operator's manual will help you and others avoid personal injury or damage to the machine. Information given in this manual will provide the operator with the safest and most effective use of the machine. Only competent and skilled persons who have fully read and understood this operator's manual are allowed to operate this machine.

Sections in your operator's manual are placed in a specific order to help you understand all the safety messages so you can operate this machine safely. You can also use this manual to answer any specific operating or servicing questions.

Your manual contains special messages to bring attention to potential safety concerns, machine damage as well as helpful operating and servicing information. Please read all the information carefully to avoid injury and machine damage. Should any questions arise regarding the information given in this booklet, please contact your local MAJOR dealer or MAJOR.

The operator is solely responsible for the safe use and maintenance of the machine. The machine must only be operated by a competent and skilled person. Setting up and adjustment must only be carried by the operator. Do not let a third party person to adjust or modify the machine in any way.

Intended use

This machine is a grass cutting machine and designed for cutting grass. Moreover, it must only be used with a suitable tractor (see "Product Specifications" section of this booklet) and driven by an adequate drive-line of the tractor PTO. All other use is strictly prohibited. Major will not be held responsible for any loss or damage caused due to a misuse of the machine.

Register Your Product and Warranty Online

To register your product through the Internet, simply go to the Support section on www.major-equipment.com. Completing the information, either online or with the product warranty card, will ensure the customer that their product receives all post sales service and important product information.

This machine is warranted for 12 months. No warranty is given where the machine is being used as a hire machine. Warranty is against faulty workmanship or parts.

Warranty covers parts only. All parts must be returned to the manufacturer. No warranty can be considered unless parts are returned. All replacement parts will be supplied on a chargeable basis until warranty has been accepted.

Tractor Requirements



Attaching the machine to the tractor will influence the stability and manoeuvrability of the tractor. Please consult your tractor manual for limitations on weight and towing ability of the tractor.

It is the operator's responsibility to ensure that the tractor is suitable for the machine. Always consult your tractor's manual for any further information required.

Recommended Horse Power requirements for the particular models are provided in the "Product Specification" section of this booklet. Using excessive power can affect the quality of cut and/or may damage the machine.


Tractors which are not suitable for the operation can sustain damage due to the weight and power requirements of the machine. Always observe the weight of machine provided in the "Product Specification" section of this booklet, compare this with the guidelines from the tractor manual and ensure that the tractor can lift the machine safely.

The machine is designed to be attached by means of a 3 point linkage connection or can be trailed (specific models). The position of the machine can be adjusted by manual or hydraulic top link.

Winged models require at least one hydraulic spool with 1/2" female quick release connection for a single acting ram/rams.

Road light kit requires a 12V 7 pin socket.

Safety

The operator's manual also explains any potential safety hazards whenever necessary in special safety messages that are identified with the word, CAUTION, and the safety-alert symbol .

Hazards associated with operating Grass Cutting Machinery

Shear Hazard

Shear hazards are created when the edges of two objects move toward or next to each other closely enough to cut relatively soft material. This can include the parts of the machine under hydraulic control when operating from transport to mowing position. Note, the wing units are designed to float independently of the centre deck & are free to move within operating limits.

Crush Hazard

Bystanders can be injured when machine is lowered into mowing position. Winged machines have crush points around the hinge areas & between the wing & main body. Always use transport locking bars when not in use (winged models only).

Rotating Blade Hazard

All persons are at risk if they place their hands or feet under the machine when it is raised from the ground when the blades are in motion.

Pinch Hazard

Pinch points are created when two objects move together, with at least one of them moving in a circle. This hazard is common in power transmission devices such as Belt Drives, Gear Drives & Rollers. Ensure all guarding is present.

Wrap Hazard

Any exposed, rotating machine component is a potential wrap point. Injuries usually occur when loose clothing or long hair catch on and wrap around rotating parts such as PTO shafts or Drive shafts on the machine. Ensure all guarding is present.

Free-wheeling parts Hazard

The heavier a revolving part is, the longer it will continue to rotate after power is shut off. This characteristic is called 'free-wheeling.' Blades, and various other components, drive shafts etc., will continue to move after power is shut off - often for several minutes. Injuries occur when:

- Operators shut off equipment, and attempt to clean or adjust a machine before components have completely stopped moving.
- Shear bolt protection device in PTO shaft shears & the mowing parts are still spinning but the primary PTO shaft is stationary. Operator awareness is the key to safety around freewheeling parts. Never raise the machine while the blades are still rotating.

Thrown objects Hazard

Machines throw material as a natural part of doing their job. Foreign objects, such as stones, sticks and other debris, may be taken into this equipment and expelled at tremendous speed. These objects are contained by the sides of the machine and by the rear/front rollers / guards / chain guards / rubber skirts depending on model of your machine. Ensure bystanders are clear from the machine & cannot be hit with debris expelled from the machine. Bystanders or animals in the path of thrown objects could be seriously injured. Never operate machine with decks raised from the ground as this makes the front/rear protection redundant.

Hydraulic Hazard (if applicable)

Hydraulic systems store considerable energy. Careless servicing, adjustment, or replacement of parts can result in serious injury. High pressure blasts of hydraulic oil can injure eyes or other body parts. The following precautions are crucial:

- Make certain the hydraulic pump is turned off.
- Lower attached equipment to the ground.
- Confirm that load pressure is off the system.

A pinhole leak in an hydraulic hose is a serious hazard. A leak may not be visible, and the only sign may be a few drops of fluid. Never inspect hydraulic hoses with your hands, because a fine jet of hydraulic fluid can pierce the skin.

Slips, Trips and Falls Hazard

Slips and falls often result from:

1. Slippery footing on the ground
2. Cluttered steps and work platforms.

The potential for slips and falls can be greatly reduced by using good judgement and practicing good housekeeping on and around equipment.

Noise Hazard

Please note that the machine is normally used outdoors and that the position of the operator is seated in the driving seat of the tractor. It is advisable to consult the prescriptions listed in tractor operator and maintenance manuals.

The acoustic pressure at a distance of 2.6m from the centre of the machine and at a height of 2.0m, with the implement operating in a no load condition can reach 90 dBA. In a loaded condition & a PTO rate of 540 (1000) rpm the value can reach 97dBA. Higher rate of PTO input will result in in higher noise levels. Always wear hearing protection.

Operating Safely

This MAJOR machine is designed to operate at a PTO rate which is stated in the Product Specifications part of this booklet. Ensure tractor PTO output is set at a correct RPM rate. This MAJOR machine must only be used for purposes outlined in the Intended Use section of this booklet. All other use is strictly prohibited.



Users should become thoroughly familiar with the contents of this manual before using, servicing and mounting the implement to the tractor and all other pertinent operations. Never wear jewellery, loose clothing such as ties, scarves, belts, unbuttoned jackets or dungarees with open zips which could become caught up in moving parts.



Always wear approved garments complying with accident prevention provisions such as non-slip shoes, ear muffs, goggles and gauntlets. Wear a jacket with reflecting stickers if the implement is used near public highways.



Consult your retailer, the Labour Health Service or your nearest equivalent authority for the information about the current safety provisions and specific regulations with in order to ensure personal safety.



ALWAYS DISENGAGE PTO, SWITCH OFF THE TRACTOR ENGINE AND ENGAGE THE PARKING BRAKE BEFORE MAKING ADJUSTMENT TO THE MACHINE.



NEVER PLACE LIMBS UNDER THE MACHINE WHILE ROTOR(S) ARE TURNING. ROTOR(S) CAN REMAIN TURNING FOR UP TO 1 MINUTE AFTER DISENGAGING PTO.

Workstation

The operator must remain seated while working the machine. If the machine is a winged unit and the wings need to be raised/lowered the operator must not leave the tractor. Always ensure the PTO has been turned off and the parking brake applied before leaving the tractor cab or carrying out maintenance.



NEVER OPERATE THE HYDRAULICS WITH THE TRACTOR SWITCHED OFF

Regulations for use of the transmission

The transmission to the gearboxes is protected throughout the machine by both PTO shafts and bolt down covers. All guarding should be kept efficient and in good condition. If the condition is poor, the guarding should be renewed before the implement is used.



UNLESS IT IS CORRECTLY PROTECTED THE TRANSMISSION COULD CAUSE DEATH SINCE IT CAN CATCH ON PARTS OF THE BODY OR CLOTHING

Ensure retaining chains are correctly anchored on all PTO shafts, preventing them from turning. Ensure drive line can turn easily within the shield. Keep spline grooves clean and greased so that PTO shaft can connect easily. Besides being described in this booklet, the method by which the PTO shaft is connected to the tractor must be checked out with the instructions in the tractor manufacturer's manual.

PTO Shaft Safety

Maximum PTO input is specified in the Product Specifications section of this booklet. Contact your nearest dealer or a specialised retail outlet if the PTO must be replaced with a longer one, since this must belong to the same power category and possess the same characteristics. An unsuitable PTO could easily break.

The tractor PTO shaft length may be altered to suit the individual tractor model. When the machine is in operation, the PTO shaft should have a minimum 1/3 engagement as shown in the diagrams. After the machine has been hitched to the tractor, it should be checked in various positions that the drive line is the correct length. If the PTO is too short and tends to slip out of place, it must be replaced with a longer one.

If the PTO shaft is too long, it should be shortened in the following way:

- Set the machine at a minimum distance from the tractor, then brake the tractor and switch off the engine.
- Separate the two halves of the PTO. Insert the female part into the tractor PTO and the male part into the machine PTO, checking that the position is correct by means of the fixing pins.
- Line up the two halves of the PTO together, keeping them parallel.
- Using a felt tip pen, match mark the place where the two halves must be shortened as shown.
- First cut shield "1" and use part "2" as a reference to cut the splined shaft.
- Proceed in the same way for the second half.
- Trim and chamfer the two cut ends of the PTO and clean off all swarf and shavings.
- Grease the two profiles and join the two halves of the PTO together.
- Mount the PTO shaft and check that its length is correct as before.

Inspections before Use



Always disengage PTO, Switch off tractor engine and engage the parking brake before making adjustments to the machine.

1. With the whole machine as level as possible, check the oil level in all gearboxes. Top up if required through the oil filler plug. The correct level is at the oil level plug.
2. Grease all lubrication points as outlined in the Maintenance section of this booklet.
3. Check parts for wear.
4. Check the blade mounting bolts are tight.
5. Ensure the gearbox shaft nuts are tight and retained in place by split pin.
6. Check tightness of all nuts, bolts and pins.
7. Ensure safety guards and flaps are in place at all times where fitted. If these become worn or missing, replace them immediately with new ones.
8. Due to the corrosive nature of grass when cut, wash down the machine when finished mowing, especially when the machine is being stored for a long period of time.

Starting Regulations



Always check that any imminently dangerous conditions have been eliminated before using the machine. Ensure all guarding is present & the operator is fully aware of the operations of the machine.



Always ensure the pins lock the PTO shaft yoke ends onto the spline shafts on both the tractor and the implement. An unlocked shaft could slip out of position, causing notable mechanical damage and serious injury to both operator and bystanders.

Product Identification

Machine Serial Numbers

If you need to contact MAJOR or your MAJOR dealer for information on servicing or spare parts, always provide the product model and serial numbers. Model and Serial number can be found on the Serial Plate located on the machine.

We suggest that you record your machine details below:

Model No: _____

Serial No: _____

Date of Purchase: _____

Dealer Name: _____

Dealer Telephone: _____



Product Specifications

The machine is propelled by using a 6 spline 1-3/8" PTO shaft (provided with the machine).

Model	MJ30-560HD
Cut Width	5.55m
Transport Width	2.4m
No. of Blades	24
No. of Rotors	6
PTO (rpm)	1000
Cutting Height	40-170mm
Weight (kg)	1750

EEC certificate of conformity for machines

(conforming to Directive 2006/42/EC)

Name of Manufacturer: Major Equipment Ltd
Address: Coolnaha, Ballyhaunis, Co. Mayo, Rep of Ireland

Tel. +353949630572
Fax +353949630788

declares in sole responsibility that the product:

Machine description and function: Rotary mower with vertical axes cutting heads which cuts grass so it can be subsequently picked up.

Model: Cyclone heavy duty mower (MJ30-560HD)


Type: _____

Serial number: _____

Technical file compiled by: Alex Kolchanov (c/o Major Equipment Ltd)

- **THE SUPPLY OF MACHINERY (SAFETY) REGULATIONS 2008.**
- **S.I. No. 299 of 2007**, Safety, Health and Welfare at Work (General Application) Regulations 2007 (Ireland).
- **Health & Safety at Work, etc. Act 1974 (c.37) (UK).**
- **EN ISO 14121-1: 2007** 'Safety of machinery. Principles for risk assessment'.
- **EN 745** - Agricultural Machinery - Rotary Mowers and Flail Mowers - Safety.
- **EN ISO 13857** - Safety of machinery: Safety distances to prevent hazard zones being reached by upper and lower limbs.

I hereby certify on behalf of Major Equipment Int. Ltd., that this machine when properly installed and operated correctly, complies with all the essential Health & Safety requirements of all legislation referred to above.

Signed: 
Date: 26/07/2019
Name: John Murphy
Position: Managing Director

Place: Coolnaha, Ballyhaunis, Co. Mayo, Rep of Ireland

Machine Safety Labels

The machine safety labels shown in this section are placed in important areas on your machine to draw attention to potential safety hazards.


On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety alert symbol. DANGER identifies the most serious hazards.

To prevent Serious Injury or Death

- Avoid unsafe operation or maintenance.
- Do not operate or work on this machine without reading and understanding the operator's manual.
- If manual is lost, contact your nearest dealer for a new manual.



To avoid injury, read the manual



Rotating blade hazard



PTO entanglement hazard - keep clear of PTO drives.

WARNING



DO NOT GO NEAR LEAKS

- High pressure of easily punctures skin causing serious injury, gangrene or death.
- If injured, seek emergency medical help. Immediate surgery is required to remove all.
- Do not use finger or skin to check for leaks.
- Lower load or relieve hydraulic pressure before loosening fittings.

High oil pressure hazard

ATTENTION!!

CHECK TIGHTNESS OF TRANSMISSION BOLTS AT EVERY SERVICE.

Check tightness of the transmission bolts

PTO TUBES MUST BE GREASED EVERY 10 HOURS

Grease PTO tubes

CHECK TIGHTNESS OF TRANSMISSION BOLTS AFTER FIRST 8 HOURS OF WORK

Check bolts



Grease points

MAX PTO INPUT 1000 RPM

- Ⓞ MAX. DREHZAHL 1000 U/MIN
- Ⓞ MAX. TOERENTAL 1000 TPM
- Ⓞ MAX. PRISE DE FORCE 1000 TOURS/MIN

Maximum PTO input

ATTENTION!





Do not engage drive while in transport position

Do not engage drive while in transport position



Moving parts


Key to Main Parts



1	Body
2	Transmission cover
3	
4	Gearbox PTO cover
5	Rear roller
6	Strap/Chain
7	Roller height indicator
8	Skid
9	Rubber skirt
10	Guards
11	A-Frame buffer stop
12	Wing
13	Blade

Blade Rotation


Blade rotation viewed from underside




Blade system

Full breakdown of the blade assembly is provided in the Spare Parts section of this booklet

1 Blade mount	7 Blade pivot bolt
2 Gearbox output shaft	8 Blade pivot bush
3 Gearbox split pin	9 Blade
4 Blade back	10 Undersole disk
5 Blade back bolt	11 Overlap Blade
6 Blade back spacer	



Drive-line gearboxes



Operating the Machine

Attaching machine to the Tractor



ALWAYS OPERATE ON LEVEL GROUND WHEN HITCHING/UNHITCHING THE IMPLEMENT. THIS WILL PREVENT DANGEROUS MOVEMENT. NEVER ALLOW ANYONE TO STAND BETWEEN THE TRACTOR AND THE MACHINE.

Three Point Linkage Models

1. Adjust both lift arms of the tractor until they are level in relation to each other.
2. Hitch the lower linkage arms to the Machine and connect the top link and PTO shaft. Ensure that the locking pins are secure.
3. With the Machine lowered in its operating position, adjust the top link until the strap is slack, allowing the Machine to produce a uniform finish in varying ground conditions.
4. Check the PTO shaft for length as described previously. Connect the PTO shaft. Ensure PTO check chains are anchored to prevent PTO guarding from rotating.
5. Connect the hydraulic hoses to the appropriate connections (selected models only).

Trailed Models

1. Adjust the tractor hitch pin so that the hitch pin is approximately 400 mm (16") from the end of the tractor PTO shaft.
2. Adjust the machine hitch eye to suit the tractor drawbar height paying particular attention to keep both height adjusting bolts as far as possible on the adjusting bracket. Careful adjustment of the hitch eye height at this stage is necessary in order to allow the machine to function safely and correctly.
3. Connect the machine to the tractor. Ensure no one is standing between the tractor and the Machine.
4. Check the PTO shaft for length as described previously. Connect the PTO shaft. Ensure PTO check chains are anchored to prevent PTO guarding from rotating.
5. Connect the hydraulic hoses to the appropriate connections (selected models only).

Transport Position



Before raising the machine wait until the transmission and the blades are completely still.
During the transport of the machine it is recommended that the PTO shaft is disconnected.

1. Check machine is hitched to the tractor as described. Ensure the tractor parking brake is applied
2. Ensure moving parts become still then transform the machine into transport position by hydraulic control
3. During the transport and any time the machine shall be raised, the raising device shall be adjusted to assure that the machine is at least 250mm over the ground.

Transport Position (Winged models only)



The transport locking bars, transport pin and axle ram stopper should always be slotted into place while transporting the machine. Doing this removes pressure from the hydraulic system. Failure to use the safety equipment can cause mechanical as well as physical damage.



Transport Speed of Trailed models should not exceed 25 km/h.

During transport move the Ram Stops up and secure with pins.



Operating the Machine/Mowing



Never place limbs under the machine while rotors are turning. Rotors can remain turning for up to 1 minute after disengaging PTO.




While operating this machine the PTO input rate should not exceed the RPM stated in the Product Specifications section of this booklet. Always operate on level ground when connecting/disconnecting the implement. This will prevent dangerous movement.



Never allow anyone to stand between the tractor and the machine. Ensure the machine is attached correctly to the tractor as previously described. Always start up the tractor PTO at a low RPM. Build up to operating speed, select a suitable forward gear & proceed to cut grass.


1. Hitch the machine as outlined in the previous section. Ensure bystanders are clear from the machine & cannot be hit with debris expelled from the machine.
2. Locate the Parking Jack on its side under the PTO shaft on the stub provided (Trailed models only)
3. Ensure the PTO stand is flipped down. (Trailed models only)
4. Check PTO shaft is fully engaged on tractor PTO splines.
5. Raise the machine by hydraulic control. (Trailed models only)
6. Flip back axle and drawbar ram stoppers. (Trailed models only)
7. Lower the machine by hydraulic control to the ground or use tractor linkage controls.
8. After clearing the vicinity of bystanders, relocate the Wing Transport Locking Bars. Lower the wings by hydraulic control. Ensure hydraulic ram is fully closed. (Winged mowers only).
9. Start up the tractor PTO at a low RPM.
10. Build up to operating speed, select a suitable forward gear & proceed to cut grass.

Move Ram Stops down for mowing. Ram Stops limit the wing lift and prevent damage to wing PTO shafts and gearboxes.



Additional adjustments

Parking stand leg must be fitted and secured with the pin before detaching machine from the tractor.



- | | |
|---|--------------------------|
| 1 | <i>Parking stand</i> |
| 2 | <i>Parking stand pin</i> |

Roller and skid setup





Always perform the adjustments on a level ground with the PTO disconnected.

Roller and skids must not become detached from the machine.

1. Skid height can be changed by locating the skid in different skid adjustment slots.
2. Roller position must be adjusted to suit the working conditions.
3. Ensure the machine is always running parallel to the ground. The front of the machine must not be lower than the back. Lock tractor arms in position.

- | | |
|---|---------------------------------------|
| 1 | <i>Roller</i> |
| 2 | <i>Skid</i> |
| 3 | <i>Skid adjustment slots</i> |
| 4 | <i>Roller height adjustment slots</i> |
| 5 | <i>Roller pivot arm</i> |




Castor wheel



Always perform the adjustments on a level ground with the PTO disconnected.

The height of the castor wheels can be adjusted. To do so unscrew the castor wheel arm mounting bolts, locate the arm in the desired position and secure by tightening the bolts. Repeat the steps for all other wheels on the machine.

1	<i>Castor wheel arm</i>
2	<i>Castor wheel yoke</i>
3	<i>Castor wheel</i>
4	<i>Castor wheel arm mounting bolts</i>
5	<i>Castor wheel yoke mounting bolts</i>



Maintenance

In order to keep your Major machine in a good working order it is necessary to conduct maintenance on a regular basis. Only competent and skilled persons who have fully read and understood this operator's manual are allowed to carry out maintenance on this machine. It is important to replace worn parts immediately with genuine Major spare parts. These parts are manufactured to the same specification as the machine and will provide the best result. Genuine Major spares can be obtained from MAJOR or your local MAJOR dealer.

All maintenance checks and operations must be carried on a firm level ground. The machine must always be disconnected from the tractor before any cleaning, lubricating and servicing operations can be carried out. If works must be carried out under the machine, ensure that the props, jacks, stands, hoists or cranes are capable of supporting the machine securely.

If emergency operations are required whilst the machine is connected to the tractor, switch off the engine of the tractor, remove the key from the ignition, engage the parking brake and disengage the PTO. An example of such emergency situation is the complete blockage of the machine in the field. To clear out the blockage follow the safety steps described above and clear out the blockage. Ensure there are no ropes, twines or wires wrapped around the rotors.


Machine storage

To prolong the life of your machine it is recommended to store it in a dry environment. Prior to parking the machine for storage, wash the machine thoroughly, especially underneath, and ensure that there is no grass or debris left on the machine. Lubricate all pivot points with EP2 type grease. Check for oil leaks and fix these if required. Any parts of the machine with damaged paint/galvanised surface must be painted.


PTO Shaft Maintenance

Guard Removal and Yoke End Greasing

1. Prise back locking tabs
2. Pull back PTO Guard
3. Grease points as shown
4. Push Guard into position
5. Click into place
6. Tie check chain



PTO Greasing Intervals



Shearbolt Replacement (if applicable)

1. Slide yoke shield back.
2. Drive out sheared bolt with hammer and punch.
3. Align holes and install new shear bolt. (Use only genuine MAJOR replacement shear bolts)
4. Slide yoke shield securely in place



Always fit PTO shaft with the shearbolt/slip-clutch end connected to the machine as directed on the PTO guarding.

Transmission Bolts

All nuts and bolts in the transmission including Rubber couplings, Star Drives, PTO Shafts and Gearboxes should be checked for tightness after mowing at the following intervals:

1st 50 Acres

1st 100 Acres

1st 250 Acres

And every 250 acres thereafter.

Roller

Check the condition of the rollerend (stub axle) at the end of every season. Roller shaft (stub) must be able to rotate freely and without excessive play. If necessary, remove the roller assembly and adjust the tightness of the bearings.

Replacement of wear parts

Blades, blade backs, blade bushing, blade bolts and nuts must be checked on a regular basis for wear and deflection. MAJOR recommends to visually check the blade assemblies every 40 hours of operation. This interval may change depending on the operational conditions.

Replace any damaged or worn parts immediately, failure to do so can result in blade breakages and can cause damage to the equipment or injuries to the operator and others nearby.

Blunt blades must be sharpened or replaced, failure to do so will result in a poor quality cut and excessive use of power from your tractor.



ENSURE BLADE ROTATION AND TIMING IS CORRECT AFTER SERVICING TRANSMISSION.



Pay attention when servicing or detaching components from the machine. Subassemblies and parts e.g. blade assemblies, gearboxes, rollers, guards, skids, wheels etc. can weigh up to 100 kilograms individually and must be supported adequately before fully detaching from the machine.

Clearing out a blockage




Always wear appropriate PPE when clearing out blockages.

If blockage of blades occurs proceed as follows:

1. Set the machine into transport position (including the top links);
2. Park the tractor on level ground, switch off the engine and remove the key from the ignition;
3. Apply a handbrake and disconnect the PTO shaft;
4. Using a pressure washer clear out the excess material built up around the blades. If the pressure washer is not available use your hand to remove the grass from around the blades, bearing in mind that there might be wires wrapped up around the rotors.

Wing shafts alignment

Ensure that after servicing the transmission, the wing pto shaft yokes are correctly aligned as shown in the diagram below – winged models only. If the shaft journals are fitted incorrectly the damage will only occur when the wings are raised into transport position.



Troubleshooting

Fault	Cause	Remedy	
Machine is getting blocked	Material too high or too much material	Reduce the ground speed but maintain required rpm from the PTO input	
	Grass is too wet	Stop and wait until grass is dried	
	Worn or dull blades	Sharpen or replace blades	
Leaves a streak of uncut or partially cut grass	Blades dull or bent	Sharpen or replace blades	
	Carrier RPM too low	Use correct PTO speed	
	Field conditions are so wet that the tractor tyre is pushing grass into mud	Too wet to mow. Stop operation and wait until grass is drier	
	Ground speed too fast	Reduce ground speed by shifting to a lower gear	
	Possible build-up materials under mower	Clean mower	
	Blades mounted incorrectly (cutting edge against direction rotation)	Change blades so that cutting edge is facing correct rotation.	
Material discharges from mower unevenly; bunches of material along with swath	Material too high and/or too much material	Reduce ground speed but maintain 540rpm at tractor PTO or make two passes over material. Raise mower for the first pass and lower to desired height for the second and cut a 90 degree angle to first pass	
Gearbox overheating	Low on lubricant	Fill to proper level	
	Improper type lubricant	Replace with proper lubricant	
	Excessive grass / debris build-up around gearbox	Remove grass, etc from machine	
Blade/bullets is scalping ground	Mower too low	Raise mower-reset wheels	
	Field is ridged	Cut field at a different angle	
	Field is too wet	Stop and wait until it is dried	
Mower will not cut.	Shear bolt sheared	Install new shear bolt	
Blades/bullets wear too fast	Cutting in sandy conditions	Increase cutting height	
	Cutting in rocky conditions	Increase cutting height	
	Blades hitting ground	Increase cutting height	
Mower seems to require excessive power	Advancing into grass too rapidly	Reduce forward travel speed	
	Hitting ground	Raise mower and reset wheels	
	Worn or dull blades	Sharpen or replace blades	
	Tractor not large enough	Use larger horsepower tractor	
Excessive vibration	Check gearbox bolts	Tighten if loose	
	Check for loose nuts on blades	Tighten if loose	
	Blade broken	Replace blades, in set	
	New blade or bolts matched with worn blade or bolts	Replace blades or bolts in sets	
	Drivelines not phased correctly. Implement and tractor yokes must be in line	Phase the driveline. Replace if necessary	
Noisy machine	Worn bearing	Replace bearings	
	Low oil in gearbox	Check level and add oil	
	Loose Parts	Check all bolts are fully tightened	
	Wrong PTO rpm rate	Check PTO rate & adjust as necessary	
	Rotors bent / broken	Replace bent or missing blades	
	Bent PTO shaft		Check PTO shafts are aligned correctly
			Check output shaft on gearboxes are not bent
		Check driveline between gearboxes is aligned.	

Gearbox leaking	Damaged oil seal	Replace seal
	Bent shaft	Replace oil seal and shaft
	Shaft rough in oil seal area	Replace or repair shaft
	Oil seal installed incorrectly	Replace seal
	Oil seal not sealing in the housing	Replace seal or use a sealant on outside diameter of seal
	Oil level too high	Drain oil to proper level
	Hole in gearbox	Replace the gearbox
	Gasket damaged	Replace gasket
	Bolts loose	Tighten bolts

Lubrication schedule

Use EP2 type grease or equivalent.

Use oil which conforms to 80W/90 standards.



	Grease points	Initially	25 hours	40 hours	80 hours	400 hours
All PTO Shaft Yoke Ends		●	●			
PTO tubes		●	●			
Wing eye pivot	4	●		●		
Spinning undersole disk	6	●		●		
Hydraulic Ram	2	●		●		
Roller stub axles	6	●		●		
Check oil levels in the gearboxes					●	
Replace oil in gearboxes						●

Spinning Undersole Disk (if applicable)

The Disk should be able spin freely. Slight side-to-side rocking motion is allowed.

In order to adjust the disk please do the following:


- Remove the assembled Spinning Undersole Disk (USD-GA1) from the machine;
- Remove seal (Item 7);
- Tighten up the lock nut (Item 8) if required;
- Place the seal back in position;
- Bolt the assembled unit (USD-GA1) back to the machine.



Spare Parts - CYCLONE





MJ30-560HD
FROM 2022

MJ30-560HD Overview



Item Part No.	Description	Qty
1 MJ30-560HD-SP-BDGA1	560HD STALK PULLER BODY	1
2 MJ30-560HD-WGGA1	560HD CYCLONE WING	1
3 MJ30-560HD-WGGA1LH	560HD CYCLONE WING (LH)	1
4 CY-920-WR	CYCLONE WING RAM	2
5 851	GREASE NIPPLE M8x1.25 STR	2

B





MJ30-560HD Body Assembly - Parts list

Item Part No.	Description	Qty
1 11RM-C16	MODIFIED OVAL GUARD	2
2 985-DCBLDHT3X-L	985 TREBLE CUT Anti-Cik	1
3 985-DCBLDHT3X-R	985 TREBLE CUT Cik	1
4 CYC-AXH-01	AXLE HOUSING	2
5 MJ30-560HD-GRD05	BODY FLAP GUARD	1
6 MJ30-560HD-ROLB10	BUFFER AXLE BODY ROLLER	1
7 MJ30-560HD-STRP01	560HD CHAIN SLING	2
8 MJ30-920-PVE03	WING PIVOT EYE	2
9 11RM-C10	COVER PIVOT	2
10 11RM-C11	COVER PIVOT	2
11 CYC-RPV10	SCRAPER PIVOT ARM	1
12 CYC-RPV10H	SCRAPER PIVOT ARM	1
13 CYC-USLK05	DIA 38mm LINKAGE PIN	2
14 MJ30-350-SD01	PARK STAND	2
15 MJ30-350-SKR01	CYCLONE REAR SKID	1
16 MJ30-350-SKR01H	REAR SKID	1
17 MJ30-560HD-BD01	560HD BODY	1
18 MJ30-560HD-CVR01	CENTRE GEARBOX COVER	1
19 MJ30-560HD-GBM01	CYCLONE GBOX MOUNT	1
20 MJ30-560HD-GBR01	BODY UNDERSIDE TROUGH	1
21 MJ30-560HD-GRD01	BODY ROLLER GUARD	1
22 MJ30-560HD-GRD20	GEARBOX COVER BRKT	2
23 MJ30-560HD-SP01	STALK PULLER MOUNT	1
24 MJ30-560HD-SP01H	STALK PULLER MOUNT	1
25 MJ30-560HD-SP10	TOP LINK MOUNT	1
26 MJ30-560HD-SP20	REAR LINKAGE MOUNT	1
27 MJ30-560HD-SP20H	REAR LINKAGE MOUNT	1
28 MJ30-560HD-SP25	CAT 3 LOWER LINK (HEAVY)	1
29 MJ30-560HD-SP25H	CAT 3 LOWER LINK (HEAVY)	1
30 MJ30-920-BF01	BUFFER STAND	4
31 MJ30-920-LK15	PIVOT PIN	4
32 MJ30-920-PVE40	WING PIVOT EYE	2
33 MJ30-920-PVE50	WING PIVOT PIN	2
34 LF140T/1	6 SPLINE 'T' BOX RATIO 1.1 (886/881)	2
35 5500-MT-GBM01	CENTER BOX MOUNT	1
36 60CSD	60mm STAR DRIVE	4
37 CYC-AXH-55	AXLE BUFFER	2
38 MJ30-560HD-GRD03	BODY REAR RUBBER FLAP	1
39 MJRC-113	113 PCD RUBBER COUPLING	2
40 MJRC-113-920	113 PCD RUBBER COUPLING	2
41 MOT10	DIA 100x100 BUFFER	4
42 MOT75	DIA 100x75 BUFFER	4
43 T292B/2	292.005 1:1.47 GEARBOX	1
44 WS601650-S	920 WING PTO SHAFT	2
45 11RM-C14	COVER MOUNT	2
46 CY-320-GBLK01	GBOX LOCK	4
47 MJ30-560HD-GRD04	GUARD RUBBER CLAMP	1
48 3000T-SKD06	ROLLER PIVOT STUB	2
49 DRV-6S-135	WING STAR DRIVE 6 SPL	2
50 T292A-S1	T292 G/BOX STUD	4
51 1/2F	1/2" FINE NYLOC NUT	6
52 111047	DIA 40 (1-3mm) INSERT	1
53 12336	CAT 3 PIN DIA 32x141mm	1
54 1/2hex10.9	1/2HEX10.9	64
55 12x112FSKS	1/2"x1 1/2" FINE SOCKET HEAD 12.9	24
56 12x134FBZP	1/2"x1 3/4" FINE BOLT	6
57 12x134FSKS	1/2"x1 3/4" FINE SOCKET HEAD 12.9	8
58 12x214FSKS	1/2"x2 1/4" FINE SOCKET HEAD 12.9	32
59 190-000-535	PTO GUARD (EXTENDED OVAL)	1
60 5/8F	5/8" FINE NYLOC NUT	4
61 57316B1	M16 AXLE STUD NUT	10
62 73	CAT 1 PIN DIA 19x76mm	2
63 AN099/10	LINCH PIN DIA 9.5	2
64 CW39174	DISC SPRING 39x17x4 (YELLOW)	2
65 DH-10404	DOCUMENT HOLDER 350x85	1
66 DSR-1-1-8	1 1/8" RATED 'D' SHACKLE	1
67 FW1	DIA 1" FLAT WASHER	12
68 FWM12	M12 FLAT WASHER	172
69 FWM12XL	M12 FLAT WASHER (EX-LARGE)	16
70 FWM16	M16 FLAT WASHER	32
71 FWM20	M20 FLAT WASHER	4
72 FWM24	M24 FLAT WASHER	2
73 FWM5	M5 FLAT WASHER	4
74 FWM8	M8 FLAT WASHER	4
75 G17366	CAT 3 TOP LINK RAM	1
76 M10	M10 NYLOC NUT	3
77 M10x50BZP	M10x50 BOLT	3
78 M12	M12 NYLOC NUT	125
79 M12x100BZP	M12x100 BOLT	2
80 M12x30SKBH	M12x30 SOCKET BUTTON HEAD 10.9	18
81 M12x30SKS	M12x30 SOCKET HEAD SCREW	2
82 M12x30SZP	M12x30 SET BOLT	19
83 M12x35BZP	M12x35 BOLT	2
84 M12x35SKBH	M12x35 SOCKET BUTTON HEAD 10.9	12
85 M12x40BZP	M12x40 BOLT	32
86 M12x40SKBH	M12x40 SOCKET BUTTON HEAD 10.9	8
87 M12x40SKS	M12x40 SOCKET HEAD SCREW	28
88 M12x50BZP	M12x50 BOLT	6
89 M16	M16 NYLOC NUT	20
90 M16x30SZP	M16x30 SET BOLT	2
91 M16x50BZP	M16x50 BOLT	12
92 M20	M20 NYLOC NUT	14
93 M20x130BZP	M20x130 BOLT	2
94 M20x60SZP109	M20x60 SET BOLT 10.9	12
95 M24	M24 NYLOC NUT	2
96 M5	M5 NYLOC NUT	4
97 M5x16SZP	M5x16 SET BOLT	4
98 M6	M6 NYLOC NUT	4
99 M6x16SZP	M6x16 SET BOLT	4
100 M8	M8 NYLOC NUT	4
101 M8x16SZP	M8x16 SET BOLT	20
102 M8x40BZP	M8x40 BOLT	4
103 NL12SP	M12 SP NORDLOCK	76
104 NL20SP	M20 SP NORDLOCK	12
105 NL8SP	M8 SP NORDLOCK	16

Further breakdown provided of items in bold text

MJ30-560HD Wing Assembly






MJ30-560HD Wing Assembly - Parts list

Item Part No.	Description	Qty					
1	985-DCBLDHTX-L	985 DISC HEAVY BLADE Anti-Clk	1	40	190592	PTO HAT	1
2	985-DCBLDHTX-R	985 DISC HEAVY BLADE Clk	1	41	190760	GUARD (COVER 760/BASE 661)	1
3	CYC-AXH-01	AXLE HOUSING	2	42	1F	1" FINE NYLOC NUT	2
4	MJ30-560HD-GRD15	WING FLAP GUARD	1	43	1x5FBZP	1"x5" FINE BOLT	1
5	MJ30-560HD-ROLW10	BUFFER AXLE WING ROLLER	1	44	1x6FBZP	1"x6" FINE BOLT	1
6	CYC-RPV10	SCRAPER PIVOT ARM	1	45	57316B1	M16 AXLE STUD NUT	10
7	CYC-RPV10H	SCRAPER PIVOT ARM	1	46	AN099/10	LINCH PIN DIA 9.5	2
8	DRV-RC-423	5500MT WING DRIVE TUBE	1	47	CW39174	DISC SPRING 39x17x4 (YELLOW)	2
9	MJ30-301-SKD01R	300 CYCLONE SKID (RH)	1	48	FW1	DIA 1" FLAT WASHER	6
10	MJ30-350-SKR01H	REAR SKID	1	49	FWM12	M12 FLAT WASHER	77
11	MJ30-560HD-CVR03	WING GEARBOX COVER	1	50	FWM12XL	M12 FLAT WASHER (EX-LARGE)	16
12	MJ30-560HD-GBM01	CYCLONE GBOX MOUNT	1	51	FWM16	M16 FLAT WASHER	24
13	MJ30-560HD-GBR03	WING UNDERSIDE TROUGH	1	52	FWM8	M8 FLAT WASHER	6
14	MJ30-560HD-GRD11	WING ROLLER GUARD	1	53	M12	M12 NYLOC NUT	59
15	MJ30-560HD-GRD20	GEARBOX COVER BRKT	2	54	M12x30SKBH	M12x30 SOCKET BUTTON HEAD 10.9	6
16	MJ30-560HD-WG01	560HD WING	1	55	M12x30SZP	M12x30 SET BOLT	21
17	MJ30-920-RS01	RAM STOP	1	56	M12x35BZP	M12x35 BOLT	2
18	MJ30-920-WA07	WING ARM	1	57	M12x35LHSKS	M12x35 SOCKET LOW HEAD 10.9	8
19	MJ30-920-WARH01H	WING ARM (FLEX HINGE)	1	58	M12x35SKBH	M12x35 SOCKET BUTTON HEAD 10.9	26
20	LF140T/1	6 SPLINE 'T' BOX RATIO 1.1 (886/881)	2	59	M12x50BZP	M12x50 BOLT	6
21	8SM-18	6 SPLINE STAR DRIVE	2	60	M16	M16 NYLOC NUT	12
22	CYC-AXH-55	AXLE BUFFER	2	61	M16x30SZP	M16x30 SET BOLT	2
23	MJ30-350-RHB00	RUBBER MOUNT	1	62	M16x50BZP	M16x50 BOLT	1
24	MJ30-560HD-GRD13	REAR RUBBER FLAP	1	63	M16x50SZP	M16x50 SET BOLT	1
25	MJ30-920-GRD09H	WING RUBBER	1	64	M16x55SKS129	M16x55 SOCKET HEAD 12.9	10
26	MJRC-113	113 PCD RUBBER COUPLING	2	65	M20	M20 NYLOC NUT	8
27	MJ30-560HD-GRD14	GUARD RUBBER CLAMP	1	66	M20x60SZP109	M20x60 SET BOLT 10.9	8
28	MJ30-920-LK14	TRANSPORT LOCK	1	67	M6x16SZP	M6x16 SET BOLT	2
29	MJ30-920-GRD08	WING CLAMP	1	68	M8	M8 NYLOC NUT	9
30	3000T-SKD06	ROLLER PIVOT STUB	2	69	M8x16SZP	M8x16 SET BOLT	16
31	MJ30-560T-HAB06	RAM CURB STOP	1	70	M8x25BZP	M8x25 BOLT	9
32	MJ30-920-PVE06	PIVOT BUSH	1	71	NL12SP	M12 SP NORDLOCK	24
33	MJ30-RMH-15	SLIDING CUBE	2	72	NL20SP	M20 SP NORDLOCK	8
34	1/2F	1/2" FINE NYLOC NUT	7	73	NL8SP	M8 SP NORDLOCK	12
35	111047	DIA 40 (1-3mm) INSERT	18	74	OB253230	PLAIN OILITE BEARING BUSH	2
36	1/2HEX10.9	1/2HEX10.9	12	75	S77	CAT 1 PIN DIA 19x127mm	1
37	12x112FSKS	1/2"x1 1/2" FINE SOCKET HEAD 12.9	12				
38	12x112SZP	1/2"x1 1/2" FINE SET BOLT	4				
39	12x134FBZP	1/2"x1 3/4" FINE BOLT	3				

Further breakdown provided of items in bold text


Front Guards assembly MJ30-560HD

MJ30-560HD Wing guard (MJ30-560HD-GRD15)




Item Part No.	Description	Qty
1 MJ30-560HD-GRD16	WING FLAP GUARD MOUNT	1
2 MJ30-560HD-GRD19	WING GUARD RUBBER	1
3 MJ30-560HD-GRD14	GUARD RUBBER CLAMP	1
4 M12	M12 NYLOC NUT	5
5 M12x30SZP	M12x30 SET BOLT	5

MJ30-560HD Body Guard (MJ30-560HD-GRD05)




Item Part No.	Description	Qty
1 MJ30-560HD-GRD06	BODY FLAP GUARD MOUNT	1
2 MJ30-560HD-GRD09	BODY GUARD RUBBER	1
3 MJ30-560HD-GRD10	GUARD RUBBER CLAMP	1
4 M12	M12 NYLOC NUT	5
5 M12x30SZP	M12x30 SET BOLT	5

Chain sling (MJ30-560HD-STRP01) (2 per machine)




Item Part No.	Description	Qty
1 MJ30-560HD-STRP02	COVER (5000403) BLUE	1
2 MJ30-560HD-STRP03	20x60GR80 CHAIN (MB8.200)	1
3 DSR-7-8	7/8" RATED 'D' SHACKLE	2

Roller axle stub assembly (CYC-AXH-01)



Item	Part No.	Description	Qty
1	CYC-AXH-10	AXLE HOUSING	1
2	CYC-AXH-21	AXLE SHAFT	1
3	CYC-AXH-22	SEAL SPACER	1
4	30210AV	NILOS RING 90x50	1
5	30210	TAPER BRG 90x50x21.75	2
6	5411001	DIA 55xDIA100.5mm WIPE SEAL	1
7	851	GREASE NIPPLE M8x1.25 STR	1
8	AGC3	DIA 90 INT CIRCLIP	1
9	DK90-10	DUST CAP 90x10	1
10	KM10	M50x1.5P LOCK NUT	1
11	MB10	DIA 50mm LOCK TAB	1

MJ30-560HD Wing PTO assembly (WS601650-S)




Item	Part No.	Description	Qty
1	NT55DF2	STAR PLATE (DIA 48mm)	1
2	T50-360-1	T50 PTO - 6 SPLINE / 48mm YOKE	1

MJ30-560HD PTO shaft

Item Part No.	Description	Machines	Safety
1 WS607400	Rear mount Walterscheid shaft 2500 1 3/4" 20 spline	MJ30-560HD with extended linkages	SB/OR M10x60 8.8 (2920Nm)
1 WS606606	Rear mount Walterscheid shaft 2500 1 3/4" 20 spline	MJ30-560HD with standard linkages	SB/OR M10x60 8.8 (2920Nm)


PTO shaft (606606) 1-3/4”(20)



Item	Part No.	Description	Qty
1	606606	PTO drive shaft with guard	1
2		Inner PTO drive shaft half with outer guard half	1
3		Outer PTO drive shaft half with inner guard half	1
4	375627	Outer guard half	1
5	375626	Inner guard half	1
13	121616	Shear bolt clutch; right-hand rotation Shearing radius 56 mm	1
14	020454	Hexagon bolt	1
21	116405	Cross and bearing kit complete	2
22	153207	Drive-in type lubrication fitting	2

23	097133	Inboard yoke	1
24	304046	Spring-type straight pin	2
25	134940	Profile tube	1
-		Shorten tube by 20 mm	
26	017660	Profile tube	1
27	097140	Inboard yoke	1
51	087276	Bearing ring	2
52	365388	Guard cone; n= Number of ribs	1
53	365305	Screw	2
54	359474	Reinforcing collar	2
55	365388	Guard cone; n= Number of ribs	1
56	044321	Safety chain	2
90	118745	Instruction manual and WARNING decal	1

Hydraulics (MJ30-560HD)



Item	Part No.	Description	Qty
1	1251-5-14	1/4" RESTRICTOR (BLACK) 204010V	1
2	560HD-HOSE-A	1/4"x 2200mm Str to Str	1
3	560HD-HOSE-B	1/4"x 1000mm Str to Block 90	1
4	560HD-HOSE-C	1/4"x 1250mm Str to Block 90	1
5	560HD-HOSE-D	1/4"x 3250mm Str to Block 90	2
6	EDOW12	1/2" DOWTY WASHER	3
7	EDOW14	1/4" DOWTY WASHER	2
8	EDOW38	3/8" DOWTY WASHER	4
9	EMM12-14	1/2"-1/4" M/M CONNECTOR	3
10	EMM14	1/4" M/M CONNECTOR	1
11	EMM3814	3/8-1/4" M/M CONNECTOR	4
12	EMMMT14	1/4" M/M/M CONNECTOR	1
13	OF06	3/8" HEX VENT	2
14	QRM12	1/2" QUICK RELEASE MALE	3


Hydraulic Ram spares

Item	Part No.	Description	Qty
1	CY-920-WR-SK	SEAL KIT FOR MJ30-560HD RAM	


NOTE: All threads hydraulic fittings and cylinders are BSPP (British Standard Parallel Pipe)

MJ30-560HD Blade assemblies

985-DCBLDHTX-L (MJ30-560HD)



985-DCBLDHTX-R (MJ30-560HD)



ITEM	PART NUMBER	DESCRIPTION	QTY
1*	USD-GA1	UNDERSOLE DISC ASSY	1
2	909GT-BM01	909GT BLADE MOUNT	1
3	BLD-25025-01	BLADE 250xDia 25	2
4	BLD-37030T-10AC	Twist Blade 370xDia 30 (Anti_Clk)	2
5	BLDB-330-175	BLADE BACK (330 CTR 17.5 deg)	1
6	BLDBX-345-17	CROSS BLADE BACK (345 CTR 17.5 deg)	1
7	BLD-26030H-WSR6	HEAVY BLADE WASHER (DIA 31)	2
8	BLDB-3000-STP1	BLADE STOP SPACER	2
9	BLDB-315-25-SY2SP08	8mm SPACER	2
10	BLDB-345-17-SP015	SPACER PLATE	2
11	BLDBXT-345-25	OVERLAP MOUNT	2
12	BB25-16-26	BLADE BUSH	2
13	BB30-20-34	BLADE BUSH	2
14	1/2F	1/2" FINE NYLOC NUT	8
15	12x134FBZP	1/2"x1 3/4" FINE BOLT	4
16	12x3FSKS	1/2"x3" FINE SOCKET HEAD 12.9	4
17	CW45215	DISC SPRING 45x21x5 (YELLOW)	4
18	DSW34	DISC SPRING 34x16.3 x2	4
19	M16	M16 NYLOC NUT	2
20	M16x50BZP	M16x50 BOLT	2
21	M20	M20 NYLOC NUT	2
22	M20x70BZP	M20x70 BOLT	2

* - further breakdown provided


ITEM	PART NUMBER	DESCRIPTION	QTY
1*	USD-GA1	UNDERSOLE DISC ASSY	1
2	909GT-BM01	909GT BLADE MOUNT	1
3	BLD-25025-01	BLADE 250xDia 25	2
4	BLD-37030T-10C	Twist Blade 370xDia 30 (Clk)	2
5	BLDB-330-175	BLADE BACK (330 CTR 17.5 deg)	1
6	BLDBX-345-17	CROSS BLADE BACK (345 CTR 17.5 deg)	1
7	BLD-26030H-WSR6	HEAVY BLADE WASHER (DIA 31)	2
8	BLDB-3000-STP1	BLADE STOP SPACER	2
9	BLDB-315-25-SY2SP08	8mm SPACER	2
10	BLDB-345-17-SP015	SPACER PLATE	2
11	BLDBXT-345-25	OVERLAP MOUNT	2
12	BB25-16-26	BLADE BUSH	2
13	BB30-20-34	BLADE BUSH	2
14	1/2F	1/2" FINE NYLOC NUT	8
15	12x134FBZP	1/2"x1 3/4" FINE BOLT	4
16	12x3FSKS	1/2"x3" FINE SOCKET HEAD 12.9	4
17	CW45215	DISC SPRING 45x21x5 (YELLOW)	4
18	DSW34	DISC SPRING 34x16.3 x2	4
19	M16	M16 NYLOC NUT	2
20	M16x50BZP	M16x50 BOLT	2
21	M20	M20 NYLOC NUT	2
22	M20x70BZP	M20x70 BOLT	2

* - further breakdown provided

3 off MJ30-560HD


3 off MJ30-560HD

Spinning Undersole Disk Assembly (USD-GA1)



Item	Part No.	Description	Qty
1	USD-015	BOLT PROTECTOR	1
2	30210-AV	NILOS RING 90x50	1
3	30210A	TAPER BRG 90x50x21.75	2
4	5411001	DIA55xDIA100.5 WIPE SEAL	1
5	820	GREASE NIPPLE 1/8" STR	1
6	AGC3	DIA 90 INT CIRCLIP	1
7	DK90-10	DUST CAP 90x10	1
8	KM10	M50x1.5P LOCK NUT	1
9	M10	M10 NYLOC NUT	6
10	M10x30SKBH	M10x30 SK BTN HD 12.9	6
11	MB10	DIA 50mm LOCK TAB	1
12	USD-002	UNDERSOLE SAUCER	1
13	USD-003	BEARING SHAFT FAB	1
14	USD-010	BEARING HOUSING	1


LF140T/1 (140.886) (140.881) (1)



Item	Part No	Description	Qty
1	0.248.7500.00	SHIM KIT 60.3x71.7	2
2	8.1.1.00041	BOLT M8X22 8,8	4
3	8.6.6.00088	PLUG 1/2"GAS	1
4	0.140.1302.00	COVER	1
5	0.124.7135.00	NAME PLATE	1
6	0.132.5002.00	GEAR Z18 M6.15	1
7	8.0.9.00026	BEARING 30207	1
8	0.140.0303.00	CASING	1
9	8.5.2.00131	SNAP RING HOLE 72 UNI7437	2
10	8.7.1.00152	DUST LIP SEAL 35X72X10	2
11	0.140.2007.00	SHAFT 1" 3/8	1
12	0.132.7107.00	CASTLE NUT M40X1.5	1
13	0.132.6002.00	GEAR Z18 M6.15	1

14	0.712.7500.00	SHIM KIT 50.3x70.3	1
15	8.0.9.00469	TAPER ROLLER BEARING 30210	2
16	8.7.1.01107	DOUBLE LIP SEAL 50X90X10	1
17	0.139.7100.00	PROTECTIVE WASHER	1
18	8.4.7.01112	COTTER PIN B4X60	1
19	0.140.3003.00	SHAFT	1
20	0.139.7101.00	BLANK WASHER	1
21	0.140.7102.00	NUT M30X2	1
22	8.6.6.00201	PLUG 3/8"GAS	2
23	8.0.1.00870	BALL BEARING 6207	1
251	8.4.7.00146	COTTER PIN B6X60	1
252	8.6.7.00269	BREATHER PLUG 1/2"GAS	1

T292B/2 (292.005) (1.47)



Item	Part No	Description	Qty
1	0.110.7500.00	SHIM KIT 65.3x79.7	2
2	0.124.7101.00	PLATE "COMER"	1
3	0.272.5001.00	CROWN WHEEL Z28 M6.22	1
4	0.272.6001.00	PINION Z19 M6.22	1
5	0.278.7103.00	LOCK NUT M40x1,5 C40 HARD. & TEMP.	1
6	0.292.0301.00	CASING	1
7	0.292.1310.00	EXTENSION	1
8	0.292.2001.00	SHAFT 1"3/8 Z6	1
9	0.292.3000.00	SHAFT 1"3/8 Z6	1
10	0.350.7500.00	SHIM KIT 46.3x65.3	1
11	0.712.7525.00	SHIM 50.3x70.3x2.5	1
12	30307	TAPER ROLLER BEARING 30307	2
13	30210	TAPER ROLLER BEARING 30210	2
14	8.1.1.00501	HEXAGON BOLT M10X22 8.8 UNI5739	8
15	8.5.2.01370	SNAP RING 80 DIN472	2
16	8.6.5.00006	PLUG EXTERNAL 3/8"GAS	4
17	8.6.7.00161	BREATHER PLUG 3/8"GAS	1
18	358010	OIL SEAL 35X80X10	2
19	559010	OIL SEAL 55X90X10	1

Notes:

All MAJOR machines must be registered when sold, to ensure that you receive the correct warranty cover and service bulletins. To register your machine for warranty, please go to the SALES & SUPPORT section of our website www.major-equipment.com and enter your details.

The Grass & Slurry Machinery Specialists | Agricultural - Professional Groundscare - Industrial

MAJOR

HOME PRODUCTS ABOUT NEWS FIND A DEALER SHOP SALES & SUPPORT CONTACT

How To Videos
Financing
Request a Demo
Technical Publications
Brochures
Register your Machine
Frequently Asked Questions

Register your Machine

Product Registration Form

Please register your machine to ensure you get the correct warranty cover and service bulletins. Please provide your full postal address.

Name * **Email ***

Address *

Address 1

Address 2



Get In Touch

Head Office

Major Equipment Intl Ltd

Ballyhaunis, Co. Mayo, F35 C891, Ireland

Tel: + 353 (0) 9496 30572

info@major-equipment.com

UK Office

Major Equipment Ltd

Major Ind. Estate, Heysham, Lancs, LA3 3JJ, UK

Tel: + 44 (0) 1524 850501

ukinfo@major-equipment.com

Netherlands Office

Major Equipment Intl Ltd (EU)

Postbus 29, NL-7700 AA Dedemsvaart, Nederland

Tel: + 31 (0) 6389 19585

euinfo@major-equipment.com

@MAJOREQUIPMENT



www.major-equipment.com